

# IMPRESSEAL

## PRODUCT INFORMATION SHEET

### DESCRIPTION:

**Impresseal** is a State-of-the-Art floor sealer finish providing the perfect blend of durability and hardness for traffic mark resistance and appearance. Ideal for use on all resilient flooring and on timber flooring. **Impresseal** will provide a long lasting finish at high appearance levels when maintained with Impresscare conventional or high speed burnishing systems, products and equipment.

### FEATURES AND BENEFITS:

- Dries to a brilliant gloss.
- Provides excellent durability and hardness.
- Excellent black heel mark resistance.
- Easy to apply and fast drying and wet look reparability
- Wet look burnishing results at 1000 R.P.M..
- Ideal for use on timber or resilient flooring such as vinyl.

### TECHNICAL INFORMATION:

Appearance	Opaque white liquid
Odour	Acrylic polymer
pH	8.5 - 9.5
Specific Gravity	1.032 ± 0 .005
Percentage Volatiles	75.0 - 75.5%
Coverage	40 - 80 m2/litre (Typical)

### USE:

**FOR VINYL:** The floor surface should be initially prepared by stripping clean any traces of wax or old polish using Impresstrip Stripper ensuring thorough removal of all slurry. Apply 3 even coats of Impresseal using a clean cotton string mop, polish or lambswool applicator.

**FOR TIMBER:** New floors - Allow 5 - 7 days after the timber seal has dried and cured before applying 3 even coats of Impresseal using a clean fine string cotton mop, lambswool or polish applicator. Ensure previous coat is dry before applying next coat. Old floors: Do NOT use on floors which have been waxed - Remove all traces of wax or old polish with Peerless Pro ALL PURPOSE STRIPPING EMULSION. Rinse floor with clean water before applying Impresseal

Allow sufficient drying time between coats; depending on atmospheric conditions and adequate ventilation 30 minutes is normal.

Note: The application of polish or finish is not suitable for use over all timber seals. If any doubts exist as to full curing of the timber seal, compatibility or contamination concerns; complete a test patch prior to coating entire surface.

### SAFETY:

#### First Aid

**Eyes:** If splashed in eyes, flush with water for 15min. Seek medical advice.

**Skin:** Wash affected area with soap and water.

**Inhalation:** If mists are inhaled, remove patient to fresh air. Seek medical advice.